



### Espera DWJ

<i>Espera</i>	<b>A</b>	<b>B</b>
<b>DWJ 1000</b>	990-1010	410
<b>DWJ 1100</b>	1090-1110	460
<b>DWJ 1200</b>	1190-1210	510
<b>DWJ 1400</b>	1390-1410	610
<b>DWJ 1600</b>	1590-1610	710